STARHUB
Universal Remote Control
User Guide

1. Controlling your home devices

The StarHub Universal Remote Control allows you to control your TV set and DVD player. It supports up to 678 brands of TV and 230 brands of DVD players. To use the remote control for your other devices, you will need to program the TV and DVD mode keys to control the relevant device listed in Section A. Please refer to the TV & DVD Setup Code List found in Section A for a list of supported brands and models. If you do not see your device brand listed in the TV & DVD Setup Code List you can follow the relevant Auto Search steps to auto search the relevant device.

2. To operate your devices

To operate your StarHub device press the STARHUB (USE THE STARHUB ICON) button. To operate your TV, press the TV button. To operate your DVD player press the DVD button.

3. To Control your TV device

To program the ID code for a particular brand of TV follow the sequence below:

1. Switch on the TV you wish to control with the remote control
2. Press and hold both the TV and OK keys.
3. Release both the TV mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate setup mode.
5. Look out for the 4-digit code of your TV set in TV & DVD Setup Code List and enter them by pressing the number keys on your remote control
6. After the fourth key has been entered, the TV mode LED will blink 3 times to indicate a successful configuration.

   If an invalid code has been entered the, ALL the mode LEDs will flash once to indicate unsuccessful configuration.

   If you are unsuccessful in the configuration repeat the steps to configure the remote control again.
7. Should you wish to program a different TV device to this remote control, repeat Steps 1-6 again with the selected TV.

4. TV auto-search function

To automatically search for your TV device, follow the auto-search steps as described below:

1. Switch on the TV you wish to control with the remote control
2. Press and hold both the TV and OK keys.
3. Release both the TV mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate successful entry into the current setup.
5. Enter the auto-search setup code 9 – 2 – 2
6. After the third key has been released, the TV mode LED will give 2 short blinks to indicate it is in auto-search mode.
7. Press and hold the PLAY key to activate the auto search. The remote control will now automatically go through its database of TV codes to search for a relevant TV device.
8. If the selected TV device responds by turning off the power, this means that auto-search has found the correct code for your TV device. Immediately release the PLAY key and press the OK key.
9. After the OK key has been released, the TV mode LED will blink 3 times to indicate successful configuration.
10. To exit the auto search mode without configuring the TV device, Press the EXIT key. After the EXIT key has been released, the TV mode LED will blink 3 times to indicate it has exited auto-search mode.

5. To control your DVD player

To program the ID code for a particular brand of DVD follow the sequence below:

1. Switch on the DVD player you wish to control with the remote control.
2. Press and hold both the DVD and OK keys.
3. Release both the DVD mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate setup mode.
5. Look out for the 4-digit code of your DVD player in TV & DVD Setup Code List and enter them by pressing the number keys on your remote control.
6. After the fourth key has been entered, the DVD mode LED will blink 3 times to indicate a successful configuration.

   If an invalid code has been entered, ALL the mode LEDs will flash once to indicate unsuccessful configuration.

   If you are unsuccessful in the configuration repeat the steps to configure the remote control again.
7. Should you wish to program a different DVD player to this remote control, repeat Steps 1-6 with the selected DVD player.

6. DVD auto-search function

To automatically search for your DVD Player, follow the auto-search steps as described below

1. Switch on the DVD you wish to control with the remote control.
2. Press and hold both the DVD and OK keys.
3. Release both the DVD mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate successful entry into the current setup.
5. Enter the auto-search setup code 9 – 2 – 2
6. After the third key has been released, the DVD mode LED will give 2 short blinks to indicate it is in auto-search mode.
7. Press and hold the PLAY key to start the auto-search mode. The remote control will now automatically go through its database of DVD codes to search for a relevant DVD player.
8. If the selected DVD device responds by turning off the power, this means that auto-search has found the correct code for your DVD device. Immediately release the PLAY key and press the OK key.
9. After the OK key has been released, the DVD mode LED will blink 3 times to indicate successful configuration.
10. To exit without configuring the DVD device, Press the EXIT key. After the EXIT key has been released, the DVD mode LED will blink 3 times to indicate it has exiited auto-search mode.

7. TV & DVD Setup Code List

TV CODES

Number	
888	0183
A	
A.R. Systems	0134
ACE	0170
Acme	0002
Acura	0004, 0032
ADA	0003
ADC	0001
Admiral	0000, 0001, 0008, 0009, 0015, 0043
Adyson	0002, 0048, 0049, 0070
Agashi	0048, 0070
Agazi	0001
AGB	0073
Aiko	0002, 0004, 0032, 0036, 0041, 0048, 0049, 0070, 0134
Aim	0134
Akai	0003, 0004, 0014, 0024, 0026, 0028, 0032, 0036, 0041, 0048, 0049, 0050, 0068, 0070, 0073, 0108, 0134
Akiba	0050, 0054, 0065, 0134
Akito	0011
Akura	0001, 0032, 0050, 0054, 0134
Alaron	0048
Alba	0002, 0004, 0012, 0015, 0028, 0032, 0037, 0048, 0050, 0052, 0072, 0094, 0134
ALBIRAL	0013
Alcyon	0042
Alkos	0027
Allorgan	0049, 0056, 0070
Allstar	0014, 0134
AMOi	0151
Amplivision	0002, 0049, 0057, 0064, 0070, 0072
Amstrad	0001, 0004, 0032, 0050, 0073, 0134
Anam	0004, 0016
Anglo	0004, 0032
Anhua	0162
Anitech	0001, 0004, 0032, 0042, 0134
Ansonic	0004, 0005, 0032, 0035, 0044, 0052, 0053, 0055, 0072, 0134
Aolinpiya	0183
Apollo	0067
Arc en Ciel	0025, 0058
Arcam	0048, 0049, 0070
Arcam Delta	0002
Aristona	0014, 0028, 0035, 0134
Arthur Martin	0064
ASA	0000, 0006, 0007, 0009, 0040, 0061
Asberg	0014, 0042, 0134
Astra	0004
Asuka	0001, 0002, 0048, 0049, 0050, 0054, 0070
Atlantic	0002, 0014, 0028, 0048, 0053, 0057, 0134
Atori	0004, 0032
Auchan	0064
Audiosonic	0002, 0004, 0014, 0025, 0028, 0049, 0050, 0060, 0070, 0072, 0134
AudioTon	0002, 0049, 0070, 0072
Ausind	0042
Autovox	0000, 0001, 0002, 0042, 0049, 0052, 0062, 0070
Awa	0034, 0048, 0070
Ayomi	0051
B	
Baihehua	0182
Baihua	0181, 0183
Baile	0180, 0181
Baird	0025, 0041, 0046, 0049, 0070
Bang & Olufsen	0000, 0074
BaoHuaShi	0183
Baosheng	0179, 0181
Basic Line	0004, 0014, 0032, 0050, 0054, 0070, 0134
Bastide	0002, 0049, 0070
Baur	0026, 0028, 0033, 0062, 0081, 0134
Bazin	0049, 0070
Beijing	0169, 0179, 0180, 0181, 0182, 0183
Beko	0072, 0087, 0134
Benq	0141, 0192
Beon	0014, 0028, 0134
Best	0060, 0072
Bestar	0014, 0072, 0134
Binatone	0002, 0049, 0070
Black Star	0022, 0052
Blacktron	0054
Blackway	0054
Blaupunkt	0003, 0081
Blue Sky	0050, 0054, 0065, 0134
Blue Star	0020, 0054
Bondstec	0022, 0052
Boots	0002, 0011, 0049, 0070
BPL	0020, 0054, 0134
Brandt	0025, 0058, 0059, 0069, 0079
Brinkmann	0134
Brionvega	0000, 0014, 0028, 0134
Britannia	0002, 0048, 0049, 0070
Bruns	0000
BSR	0023, 0056
BTC	0050
Bush	0004, 0008, 0010, 0011, 0012, 0014, 0020, 0023, 0025, 0028, 0029, 0032, 0037, 0049, 0050, 0054, 0056, 0062, 0070, 0094, 0095, 0134
C	
Cabletime	0165
Caihong	0179, 0181
Cailing	0186
Caixing	0182
Capsonic	0001
Carena	0065, 0134
Carrefour	0012, 0037, 0040
Cascade	0004, 0032, 0134
Casio	0147
Cathay	0014, 0028, 0134
CCE	0070
Centurion	0014, 0028, 0134
Century	0000, 0052
CGE	0015, 0022, 0023, 0042, 0052, 0072
Chang Cheng	0162, 0169, 0179, 0180, 0181, 0182, 0183
Changfei	0179, 0181, 0188
Changfeng	0179, 0183
Changhai	0179, 0181, 0188
Changhong	0153, 0169, 0179, 0181
Chaparral	0160
Chengdu	0179
Chimei	0146
Chunfeng	0181, 0183
Chunlan	0189
Chunsun	0179, 0181
Cimline	0004, 0032, 0050
City	0004, 0032
Clarivox	0013, 0028
Clatronic	0001, 0002, 0004, 0014, 0022, 0032, 0042, 0044, 0049, 0050, 0052, 0057, 0070, 0072, 0134
CMS	0048
CMS Hightec	0070
Concorde	0004, 0032
Condor	0002, 0014, 0032, 0044, 0048, 0052, 0054, 0057, 0072, 0134
Conrowa	0181, 0183
Contec	0002, 0004, 0012, 0032, 0034, 0037, 0048
Continental Edison	0025, 0058
Cosmel	0004, 0032, 0060
Crosley	0000, 0022, 0023, 0042, 0052
Crown	0004, 0014, 0015, 0021, 0028, 0032, 0042, 0072, 0134
CS Electronics	0002, 0022, 0048, 0050, 0052
CTC	0022, 0052
CTC Clatronic	0005
Cybertron	0050
D	
Daewoo	0002, 0004, 0014, 0032, 0048, 0049, 0050,0070, 0091, 0115, 0123, 0134
Dainichi	0048, 0050
Dansai	0001, 0014, 0028, 0036, 0048, 0070, 0134
Dantax	0017, 0028, 0029, 0072
Datsura	0021
Dawa	0134
Daytron	0004, 0032
Dayu	0180
De Graaf	0008, 0039, 0108
Decca	0002, 0011, 0014, 0028, 0041, 0049, 0070,0073, 0134
Denver	0138, 0140
Desmet	0014, 0028, 0057, 0134
Diamant	0134
Diamond	0048
Dixi	0004, 0014, 0028, 0032, 0070, 0134
DongBao	0169
DongDa	0169, 0181
Donghai	0181
DongHua	0169
DTS	0004, 0032
Dual	0002, 0023, 0025, 0049, 0053, 0062, 0070, 0134
Dual-Tec	0002, 0004, 0023, 0049, 0053
Dumont	0000, 0002, 0005, 0007, 0040, 0044, 0049, 0070
Dux	0028
Dynatron	0014, 0028, 0134
E	
Elbe	0013, 0050, 0051, 0053, 0055, 0070, 0072, 0073, 0134
Elbe-Sharp	0073
Elcit	0000, 0044, 0052, 0073
Electa	0020
ELECTRO TECH	0004
Elektra	0054
Elin	0002, 0006, 0014, 0028, 0032, 0048, 0062, 0134
Elite	0014, 0050, 0134
Elman	0005, 0023, 0044
Elta	0004, 0032, 0048
Emerson	0000, 0026, 0040, 0052, 0072, 0134
Emperor	0054
Epson	0139
Erres	0014, 0028, 0035, 0134
ESC	0070
Etron	0004
Eurofeel	0001, 0070
Euroline	0017, 0028
Euroman	0001, 0002, 0014, 0048, 0049, 0054, 0070, 0072, 0134
Europhon	0002, 0005, 0011, 0014, 0023, 0044, 0048, 0049, 0052, 0070, 0073, 0134
Expert	0053, 0064
Exquisit	0134
F	
Feilang	0181
Feilu	0179, 0181
Feiyan	0183
Feiyue	0179, 0181, 0182
Fenner	0004, 0032
Ferguson	0013, 0028, 0046, 0051, 0059, 0069, 0079
Fidelity	0002, 0008, 0018, 0048, 0134
Filmnet	0157
Filsai	0070
Finlandia	0008, 0061, 0108
Finlux	0000, 0002, 0005, 0006, 0007, 0014, 0023, 0028, 0040, 0041, 0042, 0044, 0045, 0049, 0061, 0070, 0073, 0134
Firstline	0002, 0004, 0014, 0022, 0032, 0041, 0044, 0048, 0049, 0051, 0052, 0056, 0062, 0070, 0134
Fisher	0000, 0002, 0012, 0023, 0037, 0041, 0049, 0062, 0070, 0072, 0108
Flint	0014, 0041, 0050, 0065, 0134
FNR	0044
Formenti	0000, 0002, 0023, 0024, 0028, 0042, 0048, 0057
Formenti-Phoenix	0048, 0155
Fortress	0000, 0043
Fraba	0072, 0134
France Telecom	0167
Friac	0072
Frontech	0001, 0004, 0008, 0009, 0022, 0032, 0052, 0062, 0070
Fujitsu	0041, 0044, 0049, 0070
Fujitsu General	0070
Funai	0001, 0015, 0045, 0056
G	
Galaxi	0044, 0134
Galaxis	0044, 0072, 0134
Ganxin	0179, 0182
GBC	0004, 0012, 0023, 0032, 0050
Geant Casino	0064
GEC	0002, 0009, 0014, 0026, 0028, 0038, 0041, 0049, 0062, 0070, 0073, 0134
Geloso	0004, 0008, 0023, 0032, 0052
General	0066
General Technic	0004, 0032
Genexxa	0009, 0014, 0050, 0134
Giant	0070
GoldHand	0048
Goldline	0134
GoldStar	0002, 0004, 0008, 0014, 0022, 0023, 0028, 0029, 0032, 0048, 0049, 0052, 0070, 0071, 0072, 0134
Goodmans	0001, 0004, 0012, 0014, 0028, 0032, 0036, 0037, 0041, 0045, 0049, 0068, 0070, 0071, 0073, 0134
Gorenje	0072
GPM	0050
Graetz	0009, 0026
Granada	0002, 0008, 0012, 0014, 0024, 0028, 0035, 0037, 0041, 0042, 0049, 0059, 0063, 0064, 0067, 0070, 0073, 0108, 0134
Grandin	0004, 0020, 0028, 0054
Gronic	0070
Grundig	0003, 0007, 0040, 0042, 0072, 0081, 0134
H	
Haier	0076, 0187
HaiHong	0169
Haiyan	0179, 0182, 0183
Halhong	0181
Halifax	0001, 0002, 0048, 0049, 0070
Hampton	0002, 0048, 0049, 0070
Hanseatic	0002, 0004, 0012, 0014, 0023, 0026, 0028, 0032, 0049, 0054, 0055, 0056, 0057, 0062, 0070, 0072, 0134
Hantarex	0004, 0032, 0073, 0134
Hantor	0134
Harwood	0032, 0134
Hauppauge	0030
HCM	0001, 0002, 0004, 0020, 0032, 0049, 0050, 0054, 0070, 0134
Hema	0032, 0049, 0070
Hemmermann	0062
Hifivox	0025
Higashi	0048
HiLine	0134
Hinari	0004, 0012, 0014, 0028, 0032, 0037, 0045, 0050, 0108, 0134
Hisawa	0020, 0050, 0054, 0064, 0065
Hisense	0164
Hitachi	0002, 0006, 0008, 0009, 0012, 0023, 0024, 0025, 0026, 0037, 0038, 0039, 0041, 0049, 0062, 0063, 0067, 0070, 0073, 0117, 0119, 0123, 0134
Hitch Fufian	0164, 0179, 0182, 0183
Hongmei	0179, 0181, 0182, 0183
Hongyan	0179, 0183
Hornyphon	0014, 0134
Hoshai	0050, 0065
Huafa	0181
Huanghaimei	0181
Huanghe	0179, 0181, 0182
Huanglong	0181
Huangshan	0179, 0181, 0182, 0183
Huanyu	0002, 0048, 0164, 0179, 0182, 0183
Huaqiang	0183
Huari	0183
Huodateji	0162
Hygashi	0002, 0048, 0049, 0070
Hyper	0002, 0004, 0022, 0023, 0032, 0048, 0049, 0052, 0070
Hypson	0001, 0002, 0014, 0020, 0028, 0049, 0054, 0064, 0065, 0070, 0134
Hyundai	0077
I	
Iberia	0134
ICE	0001, 0002, 0004, 0014, 0032, 0048, 0049, 0050, 0070, 0134
ICeS	0048, 0050
Imperial	0009, 0014, 0015, 0022, 0023, 0042, 0052, 0062, 0072, 0134
Imperial Cown	0180, 0183
Indesit	0010
Indiana	0014, 0028, 0134
Ingelen	0009
Ingersol	0004, 0032
Inno Hit	0002, 0004, 0014, 0028, 0032, 0041, 0042, 0049, 0050, 0052, 0070, 0071, 0073, 0134
Innovation	0001, 0004, 0029
INTER	0174
Interactive	0072
Interbuy	0004, 0022, 0032, 0052
Interfunk	0000, 0009, 0014, 0022, 0025, 0026, 0028, 0035, 0072, 0134
International	0048
Intervision	0001, 0002, 0005, 0044, 0049, 0050, 0052, 0054, 0065, 0070, 0072, 0134
Irradio	0004, 0014, 0028, 0032, 0042, 0050, 0052, 0071, 0134
Isukai	0050, 0054, 0134
IT	0172
ITC	0002, 0023, 0049, 0070
ITS	0014, 0020, 0048, 0050, 0054, 0134
ITT	0004, 0009, 0024, 0026, 0045, 0061, 0062, 0067, 0068
ITV	0004, 0017, 0028, 0029, 0052, 0134
J	
JEC	0027, 0036
Jiahua	0162
JiaLiCai	0169, 0181, 0183
Jinfeng	0162, 0179
Jinque	0179, 0181, 0183
Jinta	0181, 0182, 0183
Jinxing	0179, 0183
Juhua	0179, 0182, 0183
JVC	0012, 0014, 0037, 0046, 0050, 0118, 0211, 0212
K	
Kaige	0179, 0181, 0182, 0183
Kaisui	0002, 0004, 0020, 0032, 0048, 0049, 0050, 0054, 0065, 0070, 0134
Kamosonic	0002
Kamp	0002, 0048
Kangli	0179, 0180, 0181, 0182, 0183
Kangyi	0181, 0183
KanLi	0169
KanYi	0168
Kapsch	0009, 0053
Karcher	0002, 0004, 0006, 0013, 0028, 0044, 0054, 0072, 0134
Kawasho	0048
Kendo	0005, 0008, 0044, 0052, 0072, 0134
Kennedy	0023
KIC	0070
Kingsley	0002, 0048
Kneissel	0051, 0053, 0055, 0072, 0134
Kolster	0014, 0134
Kongque	0179, 0181, 0182, 0183
Konka	0050
Korpel	0014, 0028, 0134
Korting	0000, 0057, 0072
Kosmos	0134
Koyoda	0004
KTV	0002, 0070
Kuaile	0181, 0183
Kunlun	0162, 0179, 0180, 0183
Kuro	0021
Kyoto	0013, 0048, 0070
L	
Lasat	0072
Lenco	0004, 0032
Lenoir	0002, 0004, 0032
Lesa	0022, 0052
Leyco	0001, 0014, 0028, 0041, 0056, 0134
LG	0002, 0004, 0008, 0014, 0017, 0022, 0023, 0028, 0029, 0032, 0048, 0049, 0052, 0070, 0071, 0072, 0110, 0128, 0134, 0137, 0193, 0205, 0214
Liesenk	0028
Liesenkotter	134
Life	0001, 0004, 0029
Lifetec	0001, 0004, 0029, 0032, 0050, 0134
Lihua	0179
Lloyds	0032
Loewe	0055, 0072, 0073, 0082, 0083, 0122, 0134
Loewe Opta	0000, 0014, 0028
Logik	0034
Longjiang	0179, 0183
Luma	0008, 0026, 0028, 0032, 0053, 0134
Lumatron	0008, 0014, 0026, 0028, 0049, 0053, 0070, 0134
Lux May	0014
Luxor	0002, 0008, 0026, 0062, 0063, 0068, 0070, 0071
M	
M Electronic	0002, 0004, 0006, 0009, 0014, 0025, 0028, 0032, 0048, 0049, 0052, 0061, 0068, 0070, 0134
Magnadyne	0000, 0005, 0022, 0023, 0028, 0044, 0052, 0073
Magnafon	0002, 0005, 0042, 0044, 0048, 0073
Magnum	0001, 0004, 0029
Mandor	0001
Manesth	0001, 0002, 0014, 0028, 0036, 0049, 0056, 0057, 0070, 0134
Marantz	0014, 0028, 0134
Marelli	0000
Mark	0014, 0028, 0032, 0048, 0049, 0070, 0134
Masuda	0070
Matsui	0002, 0004, 0008, 0011, 0012, 0014, 0027, 0028, 0032, 0034, 0036, 0037, 0041, 0049, 0056, 0059, 0062, 0065, 0070, 0073, 0081, 0134, 0145
Matsushita	0016
McMichael	0038
Mediator	0014, 0028, 0035, 0134
Medion	0001, 0004, 0029, 0134
Meile	0179, 0182, 0183
MeiShi	0168
Melvox	0064
Memorex	0004, 0032
Memphis	0004, 0032, 0041, 0060
Mengmei	0182
Mercury	0032, 0134
Metz	0000, 0081
Micromaxx	0001, 0004, 0029
Microstar	0001, 0004, 0029
Minerva	0007, 0040, 0042, 0073, 0081
Minoka	0014, 0134
Mitsubishi	0000, 0012, 0014, 0037, 0134
Mivar	0002, 0042, 0048, 0055, 0070, 0071, 0072, 0073
MoDeng	0168
Motion	0042
MTC	0048, 0062, 0072
MuDan	0162, 0179, 0181, 0183
Multistandard	0044
Multisystem	0028, 0155
Multitech	0002, 0004, 0005, 0008, 0012, 0022, 0023, 0028, 0032, 0044, 0048, 0049, 0052, 0062, 0070, 0072, 0134
Murphy	0002, 0024, 0041, 0048
N	
NAD	0026
Naiko	0019
Nanbao	0181, 0183
Nansheng	0179, 0183
Naonis	0008
National	0047
NEC	0012, 0037, 0057, 0070
Neckermann	0000, 0002, 0003, 0008, 0014, 0028, 0033, 0049, 0052, 0062, 0070, 0072, 0134
NEI	0014, 0028, 0060, 0134
Nesco	0022, 0045, 0052
Network	0060
Neufunk	0032, 0134
New Tech	0004, 0014, 0032, 0049, 0070, 0134
New World	0050
Nicamagic	0002, 0048
Nikkai	0001, 0002, 0014, 0027, 0028, 0032, 0036, 0037, 0041, 0048, 0049, 0050, 0060, 0070, 0134
Nobliko	0002, 0005, 0007, 0040, 0042, 0044, 0048
Nogamatic	0025
Nokia	0009, 0024, 0026, 0061, 0062, 0067, 0068
Nordic	0070
Nordmende	0000, 0009, 0010, 0014, 0025, 0081
Nordvision	0028
Novatronic	0134
O	
Oceanic	0009, 0026, 0056, 0064
Okano	0041, 0072, 0134
ONCEAS	0002
Onwa	0050
Opera	0134
Orbit	0014, 0134
Orion	0004, 0014, 0019, 0028, 0029, 0032, 0034, 0044, 0056, 0057, 0073, 0124, 0134
Orline	0050, 0134
Ormond	0029
Orsowe	0073
Osaki	0001, 0002, 0041, 0049, 0050, 0070, 0134
Osio	0071
Oso	0050
Osume	0037, 0041, 0050
Other Brand	0184
Others	0158
Otto Versand	0002, 0003, 0012, 0014, 0020, 0021, 0023, 0025, 0026, 0028, 0033, 0037, 0043, 0049, 0052, 0056, 0057, 0062, 0070, 0073, 0081, 0134
P	
Pael	0002, 0048
Palladium	0002, 0033, 0049, 0052, 0062, 0070, 0072, 0134
Palsonic	0070
Panama	0001, 0002, 0004, 0032, 0048, 0049, 0052, 0070, 0134
Panasonic	0009, 0016, 0026, 0047, 0073, 0092, 0111, 0130, 0134, 0194, 0217, 0218, 0219, 0220
Panavision	0134
Panda	0162, 0179, 0181, 0182, 0183
Pathe Cinema	0002, 0013, 0023, 0048, 0051, 0055, 0057, 0062, 0064, 0072
Pathe Marconi	0013, 0025, 0058
Pausa	0004, 0032
Pensonic	0150
Perdio	0041, 0048, 0057, 0134
Perfekt	0134
Philco	0000, 0015, 0022, 0023, 0042, 0052, 0072, 0134
Philharmonic	0002, 0049, 0070
Philips	0000, 0002, 0014, 0017, 0023, 0026, 0028, 0035, 0038, 0078, 0080, 0086, 0096, 0097, 0098, 0101, 0106, 0107, 0121, 0125, 0126, 0129, 0133, 0134
Phoenix	0000, 0014, 0028, 0041, 0048, 0057, 0072, 0134
Phonola	0000, 0014, 0028, 0035, 0048, 0134
Pilot	0171, 0173, 0175, 0176, 0177, 0178
Pioneer	0009, 0014, 0025, 0028, 0072, 0134
Plantron	0001, 0014, 0032, 0134
Playsonic	0049, 0070
Polestar	0159
Poppy	0004, 0032
Prandoni-Prince	0008, 0026, 0042, 0052, 0073
Praxis	0161
Precision	0002, 0049, 0070
Prima	0004, 0009, 0032
Prinz	0041, 0062
Profex	0004, 0026, 0032
Profilo	0029
Profi-Tronic	0014, 0044, 0134
Proline	0014, 0035, 0041, 0134
Promac	0149, 0195
Prosonic	0002, 0028, 0029, 0047, 0048, 0070, 0072, 0134
Protech	0001, 0002, 0004, 0005, 0014, 0022, 0023, 0028, 0070
Provision	0028, 0029, 0134
Pye	0014, 0028, 0035, 0096, 0134
Pymi	0004, 0032
Q	
Qingdao	0162, 0179, 0183
Quandra Vision	0064
Quasar	0022
Quelie	0154
Quelle	0001, 0002, 0006, 0007, 0014, 0022, 0023, 0026, 0028, 0029, 0033, 0034, 0037, 0040, 0049, 0052, 0062, 0070, 0071, 0081, 0134
Questa	0012, 0037
R	
Radialva	0050, 0134
Radio Shack	0134
Radiola	0014, 0028, 0035, 0070, 0134
Radiomarelli	0000, 0022, 0052, 0073, 0134
RADIONETTE	0006
Radiotone	0014, 0032, 0072, 0134
Rank	0007, 0012, 0040
RBM	0007
Recor	0134
Rediffusion	0026
Redstar	0134
Reflex	0134
Revox	0014, 0028, 0072, 0134
Rex	0001, 0008, 0009, 0052, 0053
RFT	0000, 0041, 0055, 0072
Rhapsody	0048
R-Line	0014, 0028, 0134
Roadstar	0001, 0004, 0032, 0050
Robotron	0000
Rowa	0048, 0070
Royal Lux	0072
RTF	0000
Ruyi	0164, 0179, 0182
S	
Saba	0000, 0009, 0025, 0026, 0059, 0069, 0073, 0079
saccs	0013
Sagem	0065
Saige	0179, 0181
Saisho	0001, 0002, 0004, 0032, 0034, 0049, 0070, 0073
Salora	0008, 0009, 0021, 0023, 0026, 0062, 0063, 0071, 0073
Sambers	0005, 0042, 0044, 0073
Samsung	0001, 0002, 0004, 0014, 0028, 0032, 0041, 0048, 0049, 0070, 0071, 0072, 0085, 0088, 0090, 0094, 0114, 0127, 0131, 0134
Sandra	0002, 0048, 0049, 0070
Sanjian	0183
Sansui	0014, 0134
Sanyo	0002, 0006, 0012, 0023, 0032, 0034, 0037, 0041, 0048, 0049, 0055, 0070, 0072, 0108
Sanyuan	0179, 0181, 0182
SBR	0028, 0035, 0134
Schaub Lorenz	0009, 0026, 0062
Schneider	0002, 0014, 0023, 0025, 0028, 0035, 0049, 0050, 0052, 0053, 0062, 0070, 0134
SEG	0001, 0002, 0005, 0012, 0017, 0022, 0023, 0028, 0032, 0037, 0048, 0049, 0052, 0070, 0113, 0134
SEI	0033, 0044, 0056, 0062, 0073, 0134
SEI-Sinudyne	0000, 0005, 0009, 0073
Seleco	0008, 0009, 0012, 0023, 0053
Sencora	0004, 0032
Sentra	0027, 0032, 0036, 0050
Serino	0048, 0065
Shancha	0179, 0183
Shangguangdian	0190
Shanghai	0179, 0181, 0182, 0183, 0188
Shaofeng	0164, 0179, 0182
Sharp	0012, 0037, 0043, 0056, 0073, 0084, 0099, 0105, 0112, 0116, 0135, 0191, 0206, 0207, 0209
Shencai	0181, 0183
ShengCai	0169
Shengli	0163
Shenyang	0179, 0181, 0183
Sherwood	0181
Shorai	0045, 0056
Siarem	0000, 0005, 0023, 0044, 0073, 0081, 0134
Sicatel	0013
Siemens	0003
Sierra	0014, 0035, 0134
Siesta	0072
Silva	0048
Silver	0012, 0037, 0045
Singer	0000, 0005, 0022, 0023, 0044, 0052, 0064
Sinudyne	0000, 0005, 0023, 0028, 0033, 0044, 0056, 0062, 0073, 0134
Skantic	0009, 0063
Skyworth	0031, 0179, 0183
Sogera	0057
Solavox	0009, 0041
Songbai	0181
SongRi	0169
Sonitron	0049, 0070, 0072, 0108
Sonoko	0001, 0002, 0004, 0014, 0028, 0032, 0049, 0054, 0070, 0134
Sonolor	0009, 0033, 0064, 0108
Sontec	0014, 0028, 0056, 0072, 0134
Sony	0004, 0012, 0033, 0034, 0037, 0044, 0100, 0103, 0109, 0120, 0132, 0196, 0197, 0198, 0199, 0200, 0201, 0202, 0203, 0204, 0208, 0210, 0213, 0215, 0216
Sound & Vision	0005, 0044, 0050
Soundwave	0014, 0028, 0057, 0134
Standard	0002, 0004, 0014, 0032, 0049, 0050, 0057, 0070, 0134
Starlite	0028, 0032, 0134
Stenway	0020, 0050, 0054
Stern	0008, 0009, 0053
Strato	0032, 0134
Stylandia	0070
Sunkai	0004, 0050, 0056, 0065
Sunstar	0032, 0134
Sunwood	0004, 0014, 0032, 0134
Superla	0002, 0048, 0070, 0073
SuperTech	0032, 0048, 0134
Supra	0004, 0032
Susumu	0059
Sutron	0004, 0032
Sydney	0002, 0048, 0049, 0070
Sysline	0028
Sytong	0048
T	
Taishan	0179, 0181
Tandberg	0060
Tandy	0002, 0009, 0024, 0041, 0043, 0049, 0050, 0052, 0070
Tantec	0011
Tashiko	0002, 0008, 0012, 0037, 0038, 0048, 0049, 0070
Tatung	0002, 0011, 0014, 0028, 0034, 0041, 0049, 0070, 0073, 0134
TCL	0185
TCM	0001, 0004, 0029, 0075
Teac	0065, 0070, 0134
Tec	0002, 0004, 0022, 0023, 0024, 0032, 0049, 0052, 0059, 0060, 066, 0070
Technema	0057
Technics	0016
Technovision	0166
TEDELEX	0070
Teleavia	0025, 0058
Telecor	0049, 0050, 0053, 0070, 0134
Telefunken	0014, 0025, 0059, 0066, 0134
Telegazi	0050, 0053, 0134
Telemeister	057, 0134
Teleservice	0165
Telesonic	0134
Telestar	0134
Teletech	0004, 0017, 0022, 0028, 0032, 0052, 0060, 0134
Teleton	0002, 0037, 0049, 0053, 0062, 0070
Televideon	0048, 0057
Televiso	0064
Temco	0056
Tensai	0004, 0014, 0032, 0049, 0050, 0052, 0056, 0057, 0070, 0134
Tenson	0057
Tesmet	0014
Tevion	0001, 0004, 0029
Texet	0002, 0032, 0048, 0049, 0070
Thomson	0002, 0014, 0025, 0058, 0059, 0066, 0069, 0079, 0093, 0134
Thorn	0013, 0026, 0027, 0028, 0046, 0051, 0059, 0134
Tiane	0179
Tobo	0181, 0183
Tokai	014, 0041, 0049, 0060, 0070, 0134
Tokyo	0002, 0036, 0048
Tomashi	0020, 0054
Tongguang	0183
Toshiba	0007, 0012, 0027, 0036, 0037, 0040, 0044, 0070, 0089, 0102, 0104, 0136
Towada	0009, 0023, 0044, 0062, 0070
Trakton	0070
Trans Continens	0049, 0070, 0134
Transtec	0048
Trident	0049, 0070, 0073
Tristar	0050
Triumph	0061, 0073, 0134
U	
Uher	0009, 0014, 0042, 0053, 0057, 0072, 0134
Ultravox	0000, 0002, 0005, 0022, 0023, 0024, 0044, 0048, 0052, 0134
Unic Line	0067, 0134
Union	0148
United	0017, 0028
Universum	0001, 0006, 0014, 0022, 0023, 0028, 0033, 0034, 0037, 0040, 0042, 0049, 0052, 0056, 0060, 0061, 0062, 0067, 0068, 0070, 0071, 0072, 0081, 0134
Univox	0013, 0051, 0060, 0134
V	
Vegavox	0156
Vestel	0008, 0009, 0014, 0022, 0023, 0028, 0029, 0049, 0070, 0134
Vexa	0004, 0028, 0032, 0134
Victor	0012, 0014, 0016
Videocon	0153
VIDEOLOGIC	0048
Videologique	0002, 0048, 0049, 0050, 0070
Videosat	0022
VideoSystem	0014, 0134
Videotechnic	0048, 0049, 0057, 0070
Videoton	0063
Viewsonic	0143, 0144
Visiola	0002, 0048
Vision	0014, 0057, 0070, 0134
Visorex	0018
Vistar	0024
Vortec	0014, 0028, 0134
Voxson	0000, 0008, 0009, 0014, 0042, 0134
W	
Waltham	0002, 0013, 0024, 0049, 0063, 0070, 0134
Warumaia	0180
Watson	0014, 0028, 0050, 0057, 0134
Watt Radio	0002, 0005, 0013, 0023, 0044, 0048, 0062
Wega	0000, 0012, 0037, 0134
Wega Color	0152
Wegavox	0032
Weipai	0181
Weltblick	0014, 0028, 0057, 0070, 0134
Weston	0023
Wharfedale	0019
White Westinghouse	0002, 0005, 0028, 0048, 0057, 0060, 0134
Windstar	0054
X	
Xiahua	0179, 0181, 0183
Xiangyang	0183
Xiangyu	0181
Xihu	0179, 0182, 0183
Xinaghai	0181, 0183
Xingfu	0181
Xinsida	0188
Xrypton	0134
Xuelian	0182
Y	
Yamaha	0142
Yamishi	0049, 0050, 0054, 0065, 0070, 0134
YingGe	0169, 0181, 0182
Yokan	0134
Yoko	0001, 0002, 0004, 0014, 0028, 0032, 0048, 0049, 0050, 0070, 0072, 0134
Yonggu	0181, 0182
Yorx	0050
Youlanasi	0179, 0182
Yousida	0181
Yuhang	0181
Z	
Zanussi	0008, 0049, 0070
Zhuhai	0181

DVD CODES

A	
Aiwa	1122
Akai	1007
Akura	1040
Alba	1063, 1069, 1089, 1096, 1108
AMOi	1140
Amoisonic	1185
Apex	1017
ATLM	1148
B	
Bang & Olufsen	1043
BBK	1179
Best Buy	1036
Bosston	1030
Brand	1164
Brandt	1022, 1058, 1097
Britannia	1026
Bush	1023, 1025, 1034, 1038, 1070, 1108, 1123
C	
Caini	1192
Caixing	1171
Cambridge Audio	1028
Caravell	1141
CAT	1031, 1032
Centrex	1116
Centrum	1032
CGV	1028
Changhong	1181
CineVision	1037
Classic	1014
Clatronic	1034
Conia	1023
Conic	1149
Crown	1097
Crypto	1039
C-Tech	1029
CyberHome	1052, 1088, 1114
D	
Daewoo	1002, 1130
Dalton	1042
Dansai	1027, 1130
Daytek	1054, 1083
Dayu	1170
DCS	1142
DEC	1034
Denca	1146
Denon	1045, 1129, 1131
Denver	1034, 1040, 1132
Denzel	1024
Desay	1033
Diamond	1028, 1029
Digitor	1041
Dihe	1166, 1183
DK Digital	1084
Dmtech	1001
Doda	1176
Dongan	1180
Dongpeng	1191
Dual	1024
DVX	1029
E	
Easy Home	1036
Eclipse	1028
Elta	1003, 1107
Emerson	1011
Enzer	1024
F	
Finlux	1028
Fisher	1012
G	
Gericom	1116
Global Solutions	1029
Global Sphere	1029
Go Video	1005
GoldStar	1062
Goodmans	1034, 1038, 1116
Graetz	1024
Grundig	1008, 1116, 1121
H	
H&B	1034, 1035
Haaz	1028, 1029
Haitai	1143
Haoji	1165
HiMAX	1036
Hitachi	1005, 1016, 1024, 1036, 1056, 1063, 1210, 1213
Huabao	1156
Hyundai	1139
I	
Idall	1186
Innovation	1009, 1010, 1016
J	
Jeutech	1030
Jiabao	1200
Jieke	1172
Jinge	1184
Jingewangpai	1156
Jinwang	1158
JVC	1022, 1066, 1092, 1103, 1113, 1120, 1125, 1207
JX2026G	1201
K	
Kenwood	1117, 1168, 1182
Ketai	1157
Kingavon	1034
Kiss	1024, 1035
Koda	1034
Kongque	1196
KXD	1036
L	
Lawson	1029
Lecson	1027
Legend-V	1144
Lenco	1034
LG	1011, 1057, 1062, 1071, 1087, 1106, 1212
Life	1009, 1010
Lifetec	1009, 1010, 1016
Limit	1029
Linshuma	1159
Loewe	1008
LogicLab	1029
Luxor	1116
M	
Magnavox	1022, 1034, 1046
Magnum	1016
Malanshi	1190
Malata	1151, 1178
Marantz	1013, 1128
Matsui	1097
Maxview	1147
MBO	1020
Mediencom	1026
Medion	1009, 1010, 1016, 1038
Metz	1006
MiCO	1028
Micromaxx	1009, 1010, 1016
Micromedia	1022
Micromega	1048
Microstar	1009, 1010, 1016
Mirror	1038
Mizuda	1034, 1036
Monyka	1024
Mustek	1014, 1050
Mx Onda	1028
N	
NAD	1019
Naiko	1116
Nakamichi	1021
Neufunk	1024
Next Base	1138
Nintaus	1194
NU-TEC	1023
O	
Okon	1167
Omni	1026
Onkyo	1022, 1046, 1133
Optim	1027
Orava	1034
Oritron	1010
Other Brand	1153, 1180
P	
P&B	1034
Pacific	1029
Palsonic	1025
Panasonic	1045, 1059, 1061, 1068, 1077, 1078, 1079, 1086, 1215
Panda	1160, 1199
Pensonic	1137
Philips	1004, 1008, 1013, 1022, 1046, 1048, 1049, 1064, 1065, 1075, 1076, 1080, 1081, 1082, 1091, 1095, 1104, 1112, 1124, 1127, 1128
Philips Magnavox	1004
Pioneer	1006, 1055, 1060, 1109, 1110, 1111
Proline	1116
Promac	1136
Provision	1034
Q	
Qinghuatongfang	1163
Qisheng	1152, 1174
Qixing	1173
R	
Raite	1024
REC	1025, 1026
RedStar	1040
Reoc	1029
Revoy	1035
Risheng	1198
Roadstar	1025, 1034
Rowa	1023, 1116, 1186
Rownsonic	1032
S	
Saba	1058, 1097
Sabaki	1029
Sampo	1015
Samsung	1005, 1056, 1094
Sansui	1028, 1029
Sanyo	1098, 1105
Sast	1154, 1187
ScanMagic	1050
Schneider	1000, 1001, 1010
Scientific Labs	1029
Scott	1042, 1067
SEG	1000, 1024, 1029, 1063, 1093, 1206
Shanshui	1155, 1203
Sharp	1009, 1019, 1102
Sherwood	1018
Shinco	1177
Sigmatek	1036
Silva	1040
Singer	1028, 1029
Skymaster	1014, 1029
Skyworth	1040, 1156, 1205
SM Electronic	1029
SMC	1189
Sony	1053, 1072, 1073, 1074, 1085, 1090, 1099, 1100, 1101, 1119, 1126
Soundmaster	1029
Soundmax	1029
Standard	1029
Star Cluster	1029
Starmedia	1034
Subor	1202
Supervision	1029
Synn	1029
Tatung	1130, 1145
T	
TCL	1150, 1197
TCM	1009, 1010, 1016, 1044
Teac	1006, 1023, 1029
Tec	1040
Technics	1045
Telefunken	1032
Tevion	1009, 1010, 1016, 1029, 1042
Thakral	1195
Thomson	1047, 1058
Tokai	1024, 1040
Toshiba	1004, 1022, 1046, 1051, 1115, 1135, 1209, 1211, 1214
TruVision	1036
V	
VCD3.0	1204
Victom	1193
Victor	1161
Vtrek	1039
W	
Weifa	1162
Wharfedale	1028, 1029
Wintel	1030
X	
Xbox	1047
Xenon	1134
Xindai	1169
Xlogic	1029
XMS	1025
Y	
Yakumo	1116
Yamada	1116
Yamaha	1045, 1048, 1208
Yamakawa	1024
Yingzhibao	1175
Yukai	1050, 1118
Z	
Zaowei	1188
Zenith	1011, 1022, 1046